


Mazda RX8 rear installation guide



Overall view of assembled components in the right corner



All lengths are pre set by Wisefab.
No need to adjust before alignment.

Anti-squat adjustment

Upright has abuilt in anti-squat adjustment.
Moving the arm upwards, gives you less anti-squat.
Moving it down, gives you more.

Less anti-squat - is better over bumps on throttle
More anti-squat - Better launches, needs more power to spin the tires.

Adjusting to extreme, make sure that everything clears in the movement of the suspension



Installing the toe arm

Holes are oval for adjusting bumpsteer.
If bumpsteer is not measured leave the arm at the middle.

Recommended alignment specs

Camber: -0,5deg
Toe: 3-10mm toe in/per side



If you still have some trouble installing the kit, contact us at sales@wisefab.com, or call us +372 5562 5669